



LEG BRACKET

ASSEMBLY INSTRUCTIONS

DUX, DUXIANA and DUX Pascal-systems are registered trademark owed by Dux Design AB 2012.

Printed 2021.02.01

dux.com

HARDWARE		TOOLS NEEDED
x2 M8 20mm x4 Washer	x2 Cube	4
x2 M8 40mm ×2 Spacer		
x2 M8 60mm	x2 Bracket	Spanner 13mm or adjustable wrench (not included)
ASSEMBLING		
I. PREPARING LEGS Attach the leg bracket to the leg. Use M8 screw with washer.	M8 20mm	
	Spacer, to be used in combination with basecover/bedcover.	
II. LOW FRAME ASSEMBLY A Attach the leg bracket to the leg. Use the big washer to fill the space between the frame and the leg. Fasten with M8 40mm bolt and washer.	M8 40mm	
B Attach the leg bracket to the leg. Use the big washer to fill the space between the frame and the leg. Fasten with M8 60mm bolt and washer.	M8 60mm	